



### AVAILABLE TERMINALS

Most BZ/BA catalog listings have A2 type terminals. Several other terminal styles are shown and others are available.

### CUTAWAY OF STANDARD BASIC SWITCH




### mm/in. SOLDER (no suffix)




Use up to #14 wire.

### A2




Bottom facing 6-32 NC x .218 in. screw with cup washers. (A4 is the same as A2 except #8 screws.)

### T




Bottom facing 6-32 NC x .218 in. screw with Sems lockwashers.

### D5




6,35/.250 wide x 7,32/.030 thick quick-connect.

### D6




6,35/.250 wide x 0,81/.032 thick quick-connect.

### P4



Side facing 8-32 x .218 in. screw with cup washers.

### PC2



Self-lifting pressure plate terminals and plastic barriers for added dielectric protection.

# BZ/BA Series Available Terminals

## WARRANTY/REMEDY

Honeywell warrants goods of its manufacture as being free of defective material and faulty workmanship. Contact your local sales office for warranty information. If warranted goods are returned to Honeywell during that period of coverage, Honeywell will repair or replace without charge those items it finds defective. The foregoing is Buyer's sole remedy and is **in lieu of all other warranties, expressed or implied, including those of merchantability and fitness for a particular purpose.**

While we provide application assistance, personally, through our literature, and through the Honeywell website, it is up to the customer to determine the suitability of the product in the application.

Specifications may change at any time without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

## SALES AND SERVICE

Sensing and Control serves its customers through a worldwide network of sales offices and distributors. For application assistance, current specifications, or the name of the nearest Authorized Distributor, contact a nearby sales office or call:

### TELEPHONE

1-800-537-6945 (USA)  
1-800-737-3360 (Canada)  
1-815-235-6847 (International)

### FAX

1-815-235-6545 (USA)

### INTERNET

[www.honeywell.com/sensing](http://www.honeywell.com/sensing)  
[info@micro.honeywell.com](mailto:info@micro.honeywell.com)

---

# Honeywell

**MICRO SWITCH**  
Sensing and Control  
Honeywell Inc.  
11 West Spring Street  
Freeport, Illinois 61032



[www.honeywell.com/sensing](http://www.honeywell.com/sensing)